

## Taschenlampenbirnen, NF-Breitlinse

Socket E10

(11x24mm)



Spannung	Strom	Artikel-Nr.
2,2V	0,25A	00612225
	0,3A	00612230
	0,4A	00612240
2,4V	0,3A	00612430
	0,5A	00612450
3,3V	0,3A	00613330
3,7V	0,3A	00613730

## Taschenlampenbirnen, NF-Breitlinse

Socket P13,5s

(11,5x24mm)



Spannung	Strom	Artikel-Nr.
2,2V	0,25A	00622225
	0,3A	00622230
	0,4A	00622240
2,5V	0,3A	00622530
3,7V	0,3A	00623730

## Taschenlampenbirnen, Spitzlinse

Socket E10

(9,5x22mm)



Spannung	Strom	Artikel-Nr.
1,2V	0,22A	00631222
2,2V	0,18A	00632218
	0,25A	00632225
2,4V	0,3A	00632430
2,5V	0,2A	00632520
	0,3A	00632530
3,5V	0,2A	00633520
3,7V	0,3A	00633730

